



Meter	T-max, Maximum panel thickness	Recommended thru hole size
F-55250xx	1/2"	11/16"
F-55375xx	1/2"	11/16"
F-55500xx	1/2"	11/16"
F-55376xx	1/2"	27/32"
F-55750xx	13/16"	1-21/64"
F-55100xx	13/16"	1-21/64"
F-55200xx	13/16"	1-21/64"

Please note: Your Flowmeter will be clearly marked if you need to "Read Float at Largest Diameter" or "Read Float at Top."